

Installation Instructions
Welcome Step –RV-19 and RV-19B

Clamp step to frame or put jack under center to hold step to coach contour. Be sure to slide the step two inches aft of center of the door to compensate for the door hinges. Drill four ¼” holes and use the grade 8 bolts furnished.

Installation Instructions
Welcome Step –RV-19 and RV-19B

Clamp step to frame or put jack under center to hold step to coach contour. Be sure to slide the step two inches aft of center of the door to compensate for the door hinges. Drill four ¼” holes and use the grade 8 bolts furnished.

Installation Instructions
Welcome Step –RV-19 and RV-19B

Clamp step to frame or put jack under center to hold step to coach contour. Be sure to slide the step two inches aft of center of the door to compensate for the door hinges. Drill four ¼” holes and use the grade 8 bolts furnished.

Installation Instructions
Welcome Step –RV-19 and RV-19B

Clamp step to frame or put jack under center to hold step to coach contour. Be sure to slide the step two inches aft of center of the door to compensate for the door hinges. Drill four ¼” holes and use the grade 8 bolts furnished.

Installation Instructions
Welcome Step –RV-19 and RV-19B

Clamp step to frame or put jack under center to hold step to coach contour. Be sure to slide the step two inches aft of center of the door to compensate for the door hinges. Drill four ¼” holes and use the grade 8 bolts furnished.

Installation Instructions
Welcome Step –RV-19 and RV-19B

Clamp step to frame or put jack under center to hold step to coach contour. Be sure to slide the step two inches aft of center of the door to compensate for the door hinges. Drill four ¼” holes and use the grade 8 bolts furnished.

Installation Instructions
Welcome Step –RV-19 and RV-19B

Clamp step to frame or put jack under center to hold step to coach contour. Be sure to slide the step two inches aft of center of the door to compensate for the door hinges. Drill four ¼” holes and use the grade 8 bolts furnished.

Installation Instructions
Welcome Step –RV-19 and RV-19B

Clamp step to frame or put jack under center to hold step to coach contour. Be sure to slide the step two inches aft of center of the door to compensate for the door hinges. Drill four ¼” holes and use the grade 8 bolts furnished.

Installation Instructions
Welcome Step –RV-19 and RV-19B

Clamp step to frame or put jack under center to hold step to coach contour. Be sure to slide the step two inches aft of center of the door to compensate for the door hinges. Drill four ¼” holes and use the grade 8 bolts furnished.